


# Flow Chemistry Activation, Flow Polyreactions and Flow-Made Polymer Particles

Frankfurt, Dechema,  
COOPOL Symposium  
14. January 2015



Volker Hessel

v.hessel@tue.nl

Eindhoven University of Technology  
Department of Chemical Engineering and Chemistry


Micro Flow Chemistry and Process Technology



**Flow Chemistry = chemistry in micro-, milli- and meso-scaled flow devices;  
not naturally microfabricated: capillaries, tubes, packed-beds, monoliths, ...  
1 – 1000 t/a; 10 ml/h – 1000 l/h; 10  $\mu$ m – 5 mm ID, 5 cm – 1 m OD**

- **Activation in micro-flow = chemical intensification = flow chemistry**  
*>> as opposed to transport intensification*
- **Activation of polyreactions by transfer and chemical activation in micro-flow**  
*>> free radical, living radical, (living) cationic, living anionic, dendrimers, emulsion pol.*
- **Opportunities for polyreactions in micro-flow**
- **Opportunities for making polymeric micro- and nano-particles in micro-flow**


Lab microchip



Milli-flow  
production lines



Milli-flow pilot setups



Milli-flow  
production reactors



Flow-chemistry lab station



***"Polymerisationen in mikrostrukturierten Reaktoren: ein Überblick"***

V. Hessel, C. Serra, H. Löwe, G. Hadziioannou *Chemie, Ingenieur, Technik* **77**, 11 (2005) 39-59.

***"Micro-flow technology in polymer synthesis"***

C. Tonhauser, A. Natalello, H. Löwe, H. Frey, *Macromolecules* **45** (2012) 9551-9570.

***"Micromixer-assisted polymerization processes: a review"***

F. Bally, C. Serra, V. Hessel, G. Hadziioannou, *Chem. Eng. Sci.* **66** (2011) 1449-1462.

***"Homogeneous polymerization: benefits brought by microprocess technologies to the synthesis and production of polymers"***


F. Bally, C. Serra, V. Hessel, G. Hadziioannou, *Macromol. Reaction Eng.* **4**, 9-10 (2010) 543-561.

***"Coupling microreaction technologies, polymer chemistry, and processing to produce polymeric micro and nanoparticles with controlled size, morphology, and composition"***


C. Serra, B. Cortese, I. Ullah Khan, N. Anton, M.H.J.M. de Croon, V. Hessel, T. Ono, Th. Vandamme, *Macromol. Reaction Eng.* **7**, 9 (2013) 414-439.

***"Controlled polymerization in flow microreactor systems"***


Aiichiro Nagaki and Jun-ichi Yoshida, *Adv Polym Sci* **259** (2013) 1–50.



# FLOW POLYMERIZATIONS HAVE TIME-DEPENDENT TRANSFER INTENSIFICATION









**Top-25 cited paper on NPW**  
Illg, Hessel, Löb, *Bioorg. Medic. Chem.* 18, 11 (2010) 3627-4154

Activate  
Confine  
Orient  
Boost



Simplify  
Integrate  
Synergize  
Minimize

# GOOD MOLECULES MAY BE (TOO) SLOW ... ... YET THIS IS NOT NATURAL LAW = INTRINSIC






L. Borukhova, T. Noel, B. Metten,  
E. de Vos, V. Hessel *ChemSusChem*  
6, 12 (2013) 2220–2225

Entry	Dipolarophile	—R	Toxicity (NFPA <sup>[a]</sup> )	Cost <sup>[b]</sup> [\$ mol <sup>-1</sup> ]	t [h]	Yield [%]	T [°C]	Equiv- alents	Solvent/Additives
1 <sup>[7a]</sup>		—CN	4	12	24	72	80	1.5	neat
2 <sup>[7b]</sup>		—COOH	3	13	2	80	25	1	water-tBuOH/ascorbic acid/CuSO <sub>4</sub>
3 <sup>[7c]</sup>		—COOMe	2	45	5	48	65	1	water
4 <sup>[9]</sup>		—COOMe	0	2	28	85	135	1.2	neat




# LARGER WINDOWS COMPRISE BETTER POINTS OF OPERATION






**2a**, 95%<sup>[b]</sup>  
 $t_R = 8 \text{ min}$




**2b**, 80%  
 $t_R = 8 \text{ min}$



**2g**, 80%  
 $t_R = 8 \text{ min}$




**2c**, 91% (3:1)  
 $t_R = 8 \text{ min}$




**2d**, 95%  
 $t_R = 8 \text{ min}$



**2i**, 80%  
 $t_R = 8 \text{ min}$



**2e**, 65%  
 $t_R = 8 \text{ min}$



**2f**, 79%  
 $t_R = 8 \text{ min}$




**2k**, 70%  
 $t_R = 32 \text{ min}$

N.J.W. Straathof, H.P.L. Gemoets, X. Wang, J.C. Schouten  
1612-1617.

CHEMISTRY & SUSTAINABILITY  
**CHEM****SUS****CHEM**

ENERGY & MATERIALS



6/2014

www.chemsuschem.org

A Journal of







ChemPubSoc  
Europe

Supported by  
**ACES**

WILEY-VCH


# METAL-FREE PHOTOCATALYTIC AEROBIC OXIDATION TO THIOLS

## Photo-cat



A. Talla, B. Driessen,  
N.J.W. Straathof, L.-G.  
Milroy, L. Brunsveld, V.  
Hessel, Timothy Noël,  
*Chem. Commun.* (2014)  
DOI: 10.1002/adsc.201.


## Photo-cat



H.P.L. Gemoets, V. Hessel, T. Noël *Org. Lett.* **16**, 21 (2014) 5800-5803.



## Microrreactor

- Avoids safety concerns: due to use of oxygen with flammable solvents, especially on larger scale
- Speeds up reaction: by eliminating transfer hindrances and using harsh conditions
- Prevents catalyst deactivation: promoting desired direct oxidation of Pd(0) by oxygen rather than palladium bulk agglomeration



entry	olefin	product	t <sub>r</sub> (min)	yield (%) <sup>b</sup>
1	2a	3a	10	82; 58 <sup>c</sup>
2	2b	3b	20	75
3	2c	3c	15	72
4	2d	3d	10	92
5	2e	3e	10	83
6 <sup>d</sup>	2f	3f	10	67
7	2g	3g	20	70
8	2h	3h	15	49
9	2i	3i	20	27
10	2j	3j	20	43 <sup>e</sup>

# FREE-RADICAL POLYMERIZATION – IMPACT OF HEAT RELEASE







**Significant improvement  
in molecular weight  
distribution control**

T. Iwasaki, J. Yoshida *Macromolecules*  
38, 4 (2005) 1159-1163.

Reactor	Monomer	Yield (%)	$M_n$ ( $\times 10^3$ )	PDI ( $M_w/M_n$ )
Micro-reactor	Butyl Acrylate	89.3	19.2	3.35
	Styrene	34.2	5.3	1.74
Macro-batch reactor	Butyl Acrylate	88.0	9.3	10.3
	Styrene	29.4	5.5	1.72



# PILOT PLANT FOR RADICAL POLYMERIZATION




**Plant running at industrial site:  
Idemitsu Kosan Co. Ltd.**

T. Iwasaki, N. Kawano, J.-i. Yoshida, *Org. Proc. Res. Dev.* **10** (2006) 1126–1131.

**10 t/a 3.5m × 0.9m**



**PDI advantages over batch can be realised (only) with best micro-equipment**






C. Rosenfeld, C. Serra, C. Brochon et al. (2008) *Chem Eng J* **135S** (2008) S242-S246.

**Form factor F has linear relationship to blockcopolymer properties**





Micromixer	HPIMM		LH2
	ML45	ML20	ML50
Number of channels per inlet, $N$	16	15	10
Channel width, $W_C$ (μm)	45	20	50
microstructure thickness (μm)	250	100	300
Slit or aperture width, $W_L$ (μm)	60	60	50
Form factor, $F$ (mm <sup>-1</sup> )	0.59	0.83	1.0


C. Rosenfeld, C. Serra, C. Brochon C et al. *Lab Chip* **8** (2008) 1682-1687.

## Block copolymers from IBVE, n-butylvinylether (NBVE) + ethylvinylether (EVE)







F. Bally, C.A. Serra, C. Brochon, G. Hadziioannou *Macromol. Rapid Commun.* **32** (2011) 1820–1825.






# CONTROLLED RAFT POLYMERIZATION IMPACT OF FLOW REACTOR MATERIAL






C.H. Hornung, C. Guerrero-Sanchez, M. Brasholz, S. Saubern, J. Chiefari, G. Moad, E. Rizzardo, S.H. Thang *Org. Process Res. Dev.* **15** (2011) 593–601.

# CONTROLLED RAFT POLYMERIZATION IMPACT OF OXYGEN AND AXIAL DISPERSION






## Oxygen exclusion





## Sample broadening





C.H. Hornung, C. Guerrero-Sanchez, M. Brasholz, S. Saubern, J. Chiefari, G. Moad, E. Rizzardo, S.H. Thang  
*Org. Process Res. Dev.* **15** (2011) 593–601.

T. Wu, Y. Mei, J. T. Cabral, C. Xu, K. L. Beers *J. Am. Chem. Soc.* **126**, 32 (2004) 9880-9881.




**Atom transfer radical polymerization (ATRP) of 2-hydroxypropyl methacrylate (HPMA) was used to compare the kinetics and controllability in this reactor relative to batch reactions.**

**Rate of polymerization fairly constant and compares to batch data from**  
M. Save, J.V.M. Weaver, S.P. Armes, P. McKenna *Macromolecules* **35** (2002) 1152-1159.


**Potential for library build-up for high-throughput screening**

**Masked cation = slow reaction rate = good PDI throughout**



N. Inagaki, T. Ando, M. Sawamoto et al. *Polym Repr Jpn* **53** (2004) 2416-2417.


**Highly active cation pool = very fast reaction rate**  
**= avoid mixing masking = good PDI for good microfluidics + chemistry**



A. Nagaki, K. Kawamura, S. Suga et al. *J Am Chem Soc* **126** (2004) 14702-14703.

**Table 1** Cationic polymerization of NBVE initiated by *N*-acyliminium ion using a flow microreactor system

Run	Monomer (equiv.)	Flow rate (mL/min)	Temperature (°C)	$M_n$	$M_w/M_n$
1	10	5.0	-78	1,500	1.40
2	25	5.0	-78	2,900	1.26
3	35	5.0	-78	4,400	1.17
4	50	5.0	-78	6,700	1.14
5	50	3.0	-78	5,600	1.35
6	50	1.0	-78	6,200	2.84
7	50	5.0	-48	8,200	1.30
8	50	5.0	-27	5,500	1.34
9	50	5.0	0	6,500	1.61




Nagaki, K. Kawamura, S. Suga et al.  
*J Am Chem Soc* **126** (2004) 14702-14703.

Reactor	Monomer	Flow rate (ml/min)	$M_n$ ( $\times 10^3$ )	PDI ( $M_w/M_n$ )	Significant improvement in molecular weight distribution control
Micro- reactor	n-Butyl vinyl ether	5.0	6.7	1.14	
	n-Butyl vinyl ether	1.0	6.2	2.84	
Macro- batch reactor	n-Butyl vinyl ether	---	5.7	2.56	

**Proof of living  
polymerization by  
trapping experiment**

A. Nagaki, K. Kawamura, S. Suga, T. Ando, M. Sawamoto, Yoshida, J. *J. Am. Chem. Soc.* **126**, 45 (2004) 14702-14703.



## Cationic polymerization of diisopropenylbenzenes

initiated by a Brønsted acid (trifluoromethane-sulfonic acid) instead of conventional slower acids (such as sulfuric acid) in micro flow


Indane (**B**) content improves thermal properties

95% indane (**B**) – conventionally: 80%

T. Iwasaki, A. Nagaki, J.I. Yoshida,  
*Chem. Comm.* **12** (2007) 1263–1265.  
T. Iwasaki, J.I. Yoshida, *Macromol. Rapid Comm.* **28** (11 (2007) 1219–1224.



## Initiation






Micro-capillary reactor (250  $\mu\text{m}$ )

Amino acid NCA


Active monomer

T. Honda, M. Miyazaki, H. Nakamura, H. Maeda *Lab Chip* 8 (2005) 812-818.


## Chain growth




Poly (aminosäure)





**Reduction of polydispersity index  
by using micro-capillary reactor**




**Even at high monomer concentrations  
only weak increase in polydispersity  
index for micro-capillary reactor**



**Polydispersity index is sum of fluiddynamic and statistical effects**







**Model - Experiment**


**Benchmarking in flow**

Ref.	Setup/mixer	Monomer	Solvent	$V_{M/I}$ (ml min <sup>-1</sup> )	$T_R$ (°C)	$M_w$ (g mol <sup>-1</sup> )	Lowest PDI
[30, 31]	SIMM	Styrene	THF	–	25	11300	1.09
[30, 31]	SIMM+Cap.	Styrene	CHx	–	25	8000	1.08
[32]	Caterpillar	Styrene	CHx	1.99/0.026	25	6000	1.07
[33]	T-junc.+Cap.	Styrene	THF	6.0/2.0	-28	3600	1.07
[33]	T-junc.+Cap.	Styrene	THF	6.0/2.0	0	3200	1.08
[34]	T-junc.+Cap.	Styrene	CHx	0.017/0.017	35	5300	1.09
[34]	T-junc.+Cap.	Isoprene	CHx	0.008/0.008	30	8300	1.10
This Work	T-junc.+Cap.	Butadiene	CHx/THF	1.33/0.33	45	9500	1.04




ISSN 1862-832X MREAD 6 (12) 477-532 (2012) · Vol. 6 · No. 12 · December 2012

D 72944



## Macromolecular Reaction Engineering




12/2012

Special Series  
Sensors,  
Process Control  
and Modeling


Special Series  
New Technologies in  
Polymer Reaction  
Engineering

WILEY-VCH

B. Cortese, S. Schulz, E. Klemm, V. Hessel et al. *Macrom. React. Eng.* **6**, 12 (2012) 507–515;  
S. Schulze, B. Cortese, V. Hessel, J. Lang, E. Klemm et al. *Green Process. Synth.* **2**, 5 (2013) 381-395.



Are complex models  
(non-Newtonian; non-  
isothermal) needed?



B. Cortese, S. Schulze, M. de Croon, V. Hessel,  
E. Klemm *Macromol. Symp.* **333** (2013) 55-61.





Alles drin im Containerformat




## Das neue Maß der Dinge

Mit mobilen Konzepten für industrielle Produktion im Containerformat treibt Evonik Industries einen Wandel in der Spezialchemie voran

**Kreativer** Womit Advanced Intermediates den Kunden das Leben leichter macht  
**Gesünder** Wie neue Regeln die Schichtarbeit bei Evonik Industries verändern  
**Effizienter** Was Öladditive mit den Klimaschutzzielen der EU zu tun haben

**Microreactor system coupled directly to the electrospray ionization (ESI) source of a quadrupole time-of-flight (Q-TOF) mass spectrometer**




**Transient cationic species detected**

L.S. Santos, J.O. Metzger *Angew Chem Int Ed* **45** (2006) 977-981.

## Slow addition of glycidol monomer

A. Sunder, R. Hanselmann, H. Frey, R. Mülhaupt, *Macromolecules* 32 (1999) 4240.



D. Wilms, J. Nieberle, J. Klos, H. Löwe, H. Frey *Chem. Eng. Technol.* 30, 11 (2007) 1519-1524.



**Possible formation of „hot spots“ due to inadequate mixing and heat transfer**

### Macro Batch:

- Time Consuming (24 hours)
- Complex assembly
- Molecular weights: 500 – 10,000g/mol
- Polydispersities 1.5


### Micoreactor:

- Short Reaction Times (10-30 min)
- Easy to scale up
- Molecular weights: 500 – 700 g/mol
- Polydispersities 1.4 – 1.7


# CHARACTERIZATION OF THE CONTINUOUSLY PRODUCED HYPERBRANCHED POLYGLYCEROLS

**Residence time: 5 - 15 min (*reaction time conventional synthesis: Several hours - days*)**

Flow Rate Initiator [mmol/min]	Flow Rate Monomer [mmol/min]	Ratio Initiator : Monomer	M <sub>w</sub> (NMR)	M <sub>n</sub> (GPC) PS Standards	M <sub>n</sub> (GPC) PEG Standards	M <sub>w</sub> / M <sub>n</sub>
3.44	17	1 : 4.95	910	690	620	1.5






D. Wilms, J. Nieberle, J. Klos, H. Löwe, H. Frey  
*Chem. Eng. Technol.* 30, 11 (2007) 1519-1524.







S. Liu, C.H. Chang, C.H. Chem.  
*Eng. Technol.* **30**, 3 (2007) 334–340.




# MINIEMULSION POLYMERIZATION - REVERSIBLE ADDITION-FRAGMENTATION CHAIN-TRANSFER (RAFT)

**Styrene homopolymerisation: Triton X-405 / SDS + Costabiliser  
hexadecan + potassium persulfate + RAFT agent PEPDTA**



**Proof of living nature**




**Higher PDI for the microtube reactor:  
back-mixing and axial dispersion**

- **Excellent stability of emulsions: no latex separation and coalescence**



## Taylor flow



*Increase in space-time yield by 200*



Dimension	Laboratory scale	Industrial scale
Volume [l]	0.673	100.2
Length [mm]	1107	5867
Gap length [mm]	5.2	27.56
Length/Gap length	213	213


D. Ruttgers, I. Negoita, W. Pauer, H.-U.  
Moritz *Macromol. Symp.* **259** (2007) 26-31.

## Dean vortices in smart-scale reactors




F.G. Lueth, W. Pauer,  
H.-U. Moritz *Macromol. Symp.* **333** (2013) 69-79.

Mixing poly(ethyleneglycol)-4000 diacrylate with acryloyl-poly(ethylene-glycol) linked with adhesive ligands (RGDS) for endothelial cells (HUVEC)



# STATISTICAL COPOLYMER-BRUSH COMPOSITION GRADIENT BY SURFACE-INITIATED ATOM TRANSFER RADICAL POLYMERIZATION (ATRP)




**Water / isopropyl alcohol solutions with isobutyric acid *n*-butyl ester (IABE) and 2-N,N-dimethylamino ethyl methacrylate (DMAEMA) as monomers.**


C. Xu, S. E. Barnes, T. Wu, D. A. Fischer, D. M. DeLongchamp, J. D. Batteas, K. L. Beers *Adv. Mater.* **18** (2006) 1427–1430.

## Kinetic investigation:

T. Wu, Y. Mei, J. T. Cabral, C. Xu, K. L. Beers *J. Am. Chem. Soc.* **126**, 32 (2004) 9880-9881.



## Automatic samplings, dilutions, and injections every 12 min




C. Rosenfeld, C. Serra, S. O'Donohue et al. *Macromol React Eng* 1 (2007) 547-552.



## Bifurcation analysis and grade transition dynamic optimization for NMP of styrene in a tubular reactor

A.G. Zitlalpopoca-Soriano, E. Vivaldo-Lima, A. Flores-Tlacuahuac *Macromol React Eng* 4 (2010) 599-612.

## Terrace cutting and T-type or coaxial flow in jet or stripping mode






I.U. Khan, C.A. Serra, N. Anton, T. Vandamme *J Control Release* **172**, 3 (2013) 1065-74.





# FUNCTIONAL POLYMER BEADS: MONODISPERSE ACRYLIC MICROSPHERES


T. Nisisako, T. Torii, T. Higuchi *Chem. Eng. J.* **101**, 1-3 (2004) 23–29.





**1,6-Hexanediol diacrylate:**  
disperse organic liquid phase.



**Polyvinyl alcohol (PVA)**  
aqueous solution (2.0 wt.%):  
continuous phase liquid.

**Initiator of photo-induced  
polymerization: DAROCUR®  
1173, Ciba Specialty Chemicals  
K.K., Japan)**







Reference	Year	Polymer	Diameter [μm]	CV
Dendukuri et al.[1]	2005	Not specified	40	—
Seo et al.[3]	2005	TPGDA	<100	0.02
Lewis et al.[8]	2005	TPGDA	120	0.02
Chen et al.[9]	2009	Complex	60	—
Hwang et al.[10]	2008	PEGDA	30	0.013
Okubo et al.[2]	2012	PS	20	—
Okubo et al.[2]		PMMA	120	—
Liu et al.[4]	2011	PBA	100	—
Nie et al.[11]	2005	TPGDA	50	0.025
Choi et al.[12]	2008	PNIPAM	70	1.1
Zourob et al.[13]	2006	Polymethyl acrylates	10	1.8
Nisisako et al.[14]	2004	PVA	50	1




M. Zourob, S. Mohr, A.G. Mayes, A. Macaskill,  
N. Pérez-Moral, P.R. Fielden, N.J. Goddard  
*Lab Chip* **6** (2006) 296-301.




M. Seo, Z. Nie, S. Xu, P.C. Lewis, E. Kumacheva, E. *Langmuir* **21** (2005) 4773-4775.

S. Xu, Z. Nie, M. Seo, P. Lewis, E. Kumacheva, H. A. Stone, P. Garstecki, B. Douglas, G.M. Whitesides, *Angew. Chem. Int. Ed.* **44**, 5 (2005) 724-728.




W. Jeong, J. Kim,  
S. Kim, S. Lee,  
G. Mensing, D. J.  
Beebe, *Lab Chip*  
4 (2004) 576-580.


## Microfibers



## Microtubes




## Responsive woven fabric fibers





Also shown: biosensing fibers







## Shape patterning



D. Dendukuri, D.C. Pregibon, J. Collins, T.A. Hatton, P.S. Doyle *Nat. Mater.* **5** (2006) 365-369.




## Functional compartments




D. Dendukuri, T.A. Hatton, P.S. Doyle *Langmuir* **23** (2007) 4669-4674.

# POLYMER CORE-POLYMER SHELL PARTICLES




**Poly(acrylamide) core-  
poly(tri(propylene glycol)  
diacrylate) shell particles**

Z. Chang, C.A. Serra, M. Bouquey,  
L. Prat, G. Hadziioannou *Lab Chip*  
9 (2009) 3007–3011








Silicon oil phase with sorbitan monooleate (SPAN 80) + monomer streams  
TPG-DA or EGDMA + HCPK




Trippropylene glykol diacrylate  
+ acrylic acid + HCPK






**Highly shape-anisotropic particles from liquid crystalline elastomers with defined director field configurations**

C. Ohm, N. Kapernaum, D. Nonnenmacher, F. Giesselmann, C. Serra, R. Zentel *J. Am. Chem. Soc.* **133** (2011) 5305–5311.




Expansion





Contraction

**Movement during phase transition from nematic to isotropic phase**

**> Application as actuators**






## Colloid-filled hydrogel granules




Nie, Z.; Li, W.; Seo, M.; Xu, S.; Kumacheva, E. *J. Am. Chem. Soc.* **128** (2006) 9408 -9412.

Shepherd, R. F.; Conrad, J. C.; Rhodes, S. K.; Link, D. R.; Marquez M.; Weitz, D. A.; Lewis, J. A. *Langmuir* **22** (2006) 8618-8622.





## Variation of the Janus pattern and outer shape to control drug release


(a) Core-shell  
2-2  $\mu\text{L}/\text{min}$



(b) Acorn-like  
3-2  $\mu\text{L}/\text{min}$



(c) Acorn-like  
4-2  $\mu\text{L}/\text{min}$




(d) Bicompartimental  
Janus 5-2  $\mu\text{L}/\text{min}$







I. U. Khan, C.A. Serra, N. Anton, X. Li, R. Akasov, N. Messaddeq I. Kraus, Th.F. Vandamme *Int. J. Pharmaceutics* **473** (2014) 239-249.



R. C. Hayward, A. S. Utada, N. Dan, D. A. Weitz *Langmuir* **22**, 10 (2006) 4457-4461.




**Polystyrene-*block*-poly(ethylene oxide) diblock copolymers**



**Polymeric vesicles, or polymersomes, are of interest for the encapsulation and delivery of active ingredients.**

# NARROWLY DISTRIBUTED COPOLYMER VESICLES OF DIFFERENT SHAPE (POLYSOMES)



R. Thiermann, W. Müller, A. Montesinos-Castellanos, D. Metzke, P. Löb, V. Hessel, M. Maskos, *Polymer* **53**, 11 (2011) 2205-2210.

**Amphiphilic poly(butadiene)-b-poly(ethylene oxide) (PB130-b-PEO66) block copolymer**

**Key:** controlled mixing process of polymer/THF and water by micromixers for defined self-assembly

**DLS:** sizes and size distribution

**TEM:** **s**pherical, **c**ylindrical, **w**orm-like and **d**isk micelles, **v**esicles


Mixing parameters and characterization results for CPMM samples 1B.

Sample	Mixing parameters			Characterization after THF evaporation			
	Flow rate (ml/min)		Volume ratio H <sub>2</sub> O:P/THF	C <sub>p</sub> (g/l)	DLS <R <sub>h</sub> > (nm)	μ <sub>2</sub> (90°)	TEM Morphology
	H <sub>2</sub> O	P/THF					
CPB1	10.00	0.24	42:1	1.0	35	0.13	<u>s</u> , c, v
CPB2	2.10	0.05	42:1	1.0	41	0.13	<u>s</u> , v
CPB3	10.00	0.16	63:1	0.7	51	0.13	<u>s</u> , v
CPB4	10.00	0.12	84:1	0.5	56	0.19	s, <u>v</u>
CPB5	10.00	0.10	105:1	0.4	65	0.17	s, v
CPB6	6.30	0.05	126:1	0.4	71	0.18	s, w, d, v
CPB7	7.35	0.05	147:1	0.3	92	0.16	s, w, v

P = PB<sub>130</sub>-PEO<sub>66</sub>-B polymer; C<sub>p/THF</sub> = 42 g/l; C<sub>p</sub> = final polymer concentration in water; s = spheres, v = vesicles, c = cylinders, w = worms, d = discs; underlined = dominating morphology; DLS: <R<sub>h</sub>> = <1/R<sub>h</sub>><sub>z</sub><sup>-1</sup>.




# MICROENCAPSULATION BY PRECIPITATION OF DROPLETS FROM IN MICROMIXER




## Solution-extraction process


- Extraction: aq. polyvinylalcohol + polysorbate 20-solution
- Micro-capsules: poly-lactide-co-glycolide (resomer, RG502H, RG503, RG503H + RG752)
- Model protein: bovin serum albumin (BSA, fraction V),

S. Freitas, A. Walz, H. P. Merkle, B. Gander, *J. Microencapsulation* **20**, 1 (2003) 67-85.






Poly(lactide-co-glycolide) (PLGA) microparticles with bovine serum albumin bearing fluorescein isothiocyanate (FITC-BSA)






**Demonstration: deliver  
a model antigen to  
human dendritic cells**

**Sensitivity to flow  
and particle size  
variation**




**Fluorescence:  
distribution of  
the antigen**






## Surface-enhanced Raman scattering (SERS)


**Strong SERS effect:**  
Characteristic Raman signals of aqueous solutions of adenine detected down to  $0.1 \mu\text{M}$  by the use of single sensor particles




Two-step, three-component formation of the cucurbit[8]uril (CB[8]) ternary complex in water with methyl viologen (MV2p) (blue) and naphthol (Np)




B



C



D




J. Zhang, R. J. Coulston, S. T. Jones, J. Geng, O. A. Scherman, C. Abell, *Science* **335** (2012) 690.





# LIFT-FORCE PARTICLE CLASSIFIER

Prof. Okawara, Nobuo Oozeki, Tokyo Institute of Technology

Fig. 20  $\mu\text{m}$  at  $De=60$




Lift force



- **20  $\mu\text{m}$  particle**


S. Okawara, N. Oozeki, K. Ogawa, P. Löb,  
V. Hessel *AIChE J.* **55**, 1 (2009) 24-34.

## Nanoprecipitation by hydrodynamic focusing



N. Kolishetti, S. Dhar, P.M. Valencia et al. *Proc Natl Acad Sci USA* **107**, 42 (2010) 17939-17944.

## Reverse emulsion method







L.H. Hung, S.Y. The, J. Jester, A.P. Lee *Lab Chip* **10** (2010) 1820-1825.

**Drugs encapsulated: platinum prodrug, docetaxel, doxorubicine, sorafenib**




# 3D MICROFLUIDICS FOR POLYMER NANOPARTICLES (13 – 150 nm)




M. Rhee, P.M. Valencia, M.I. Rodriguez et al. *Adv Mater* **23**,12 (2011) H79-83.

J. Sun, Y. Xianyu, M. Li et al. *Nanoscale* **5** (2013) 5262-5265.


## Cefuroxime axetil, CFA



## CFA nanoparticles *Flow*




## Raw CFA



## Commercial CFA

*Spray drying*




Volker Hessel, Dana Kralisch,  
Norbert Kockmann

 **WILEY-VCH**

# Novel Process Windows

Innovative Gates to Intensified  
and Sustainable Chemical Processes



DE GRUYTER GRADUATE

# FLOW CHEMISTRY

ORGANIC SYNTHESIS IN MOTION

FERENC DARVAS  
GYÖRGY DORMAN  
VOLKER HESSEL (EDS.)

DE GRUYTER

2012 VOLUME 1 NUMBER 1  
ISSN 2191-9542 e-ISSN 2191-9550

# GREEN PROCESSING & SYNTHESIS

EDITOR-IN-CHIEF  
Volker Hessel

DE  
G

[www.degruyter.com/gps](http://www.degruyter.com/gps)



# SFP Group: Micro Flow Chemistry and Process Technology (31 members)



Dr. T. Noel,  
Assistant prof.



Dr. Q. Wang  
Assistant prof.



G. Kolb  
Part-time prof.



N. Straathof  
PhD



E. Shahbazali  
PhD



M. Shang  
PhD



S. Sundaram  
PhD




I. Dencic  
PhD



I. Vural,  
PhD



S. Stouten,  
PhD



H. Gemoets  
PhD



B. Spasova  
PhD at IMM/TUD



J. Tibhe,  
PhD



A. Anastasopoulou  
PhD



B. Patil  
PhD



L. Borukhova  
PhD



J. Smit  
Editorial Assistant



A. Hemert  
Secretariat

# QUESTIONS??

*Art Galley of Western Australia*

